

Western Instruments

Established 1965

26509 Township Road 543
Sturgeon County, Alberta
T8T 1M1 Canada

Phone: (780) 459-6720
Fax: (780) 459-7837
E-Mail: info@westerninstruments.com

Web: www.westerninstruments.com

W-DMB Kit (Basic Dry Method)



W-DMB Kit
Illustrated with a
WC-6 Yoke
(WC-6-DMB)

Western's MPI Kits are offered in a great variety of configurations. Our Basic Dry Method Kit is supplied in our standard #3 Case (above). The model illustrated above is a WC-6--DMB Kit (Basic Dry Method) which includes the following items;

- WC-6, AC Yoke
- Powder Bulb.
- Field Indicator (Magnetometer).
- Calibration Certificate.
- Carrying Case (14.7" x 10.6" x 3.3")
- Operator Instructions
- 2 x ¾ Pounds (350g) of Dry Method Powder: Red, and Yellow

Note: The W-WMB Kit can be supplied with any model of W-Series Yoke, with a custom fitted Carrying Case.

The W-DMB Kit is Ideal for a shop just starting a Magnetic Particle Inspection Program, or a Field Inspector who wants a light and compact MPI Kit.

Phone: (780) 459-6720 Fax: (780) 459-7837 Web: www.westerninstruments.com E-Mail: info@westerninstruments.com