



## W-SWF Wet Fluorescent MPI Kit



Kit Illustrated with  
a WC-8 DC Yoke.  
(WC-8-SWF)

The W-SWF Kit offers the inspector the ultimate in convenience for fast spot checks, or spending a couple of hours performing a critical Wet Fluorescent Inspection. While illustrated above with a WC-8 (12 Volt DC Yoke and Battery), our WC-9 Cordless Yoke is the logical choice to equip this kit with. The Flash Light style UV Lamp (Western's SPR-365) uses state of the art LED technology to produce a high intensity Black Light. The combination of the Cordless Yoke and the Flash Light style UV Lamp, gives the inspector the versatility and convenience with a single case!

### W-SWF Wet Fluorescent Kit (Self Contained) (Illustrated with WC-8)

- Carrying Case
  - Economy Pie Gauge
  - Field Indicator (Magnetometer).
  - UV LED Flash Light\*
  - Aerosol Cans of; (375ml /16 oz.)
    - 4 – Fluorescent Particle Bath
    - 4 – Cleaner Remover
  - Operator Instructions
- \*Wrist Strap. Battery Charger, Spare Battery, UV Spectacles, Instruction Manual, and Calibration Certificate.

Note: The W-SWF Kit can be supplied with any model of W-Series Yoke, and is supplied with Sherwin Incorporated® Aerosols, like all of our Wet Method Kits.