

Western Instruments

Established 1965

26509 Township Road 543
Sturgeon County, Alberta
T8T 1M1 Canada

Phone: (780) 459-6720
Fax: (780) 459-7837
E-Mail: info@westerninstruments.com

Web: www.westerninstruments.com

W-WD Kit (Wet / Dry Method)



W-WD Kit Illustrated
with a WC-6 Yoke.
(WC-6-WD)

Western's MPI Kits are offered in a great variety of configurations. Our Wet / Dry Method Kit is supplied in our standard #6 Case. Our part number for a WC-6 Wet / Dry Method Kit (as illustrated above) is WC-6-WD. However, any model of Yoke can be supplied and upgraded with a W-WD to our standard #6 Case, which provides ample room for;

- WC-6 AC Yoke
- 16 oz. (375ml) Aerosol Cans of;
2 x Cleaner / Remover, 1 White
Contrast Paint, & Black Oxide.
- Operator Instructions
- Carrying Case (18.5" x 13" x 10")
- Powder Bulb.
- 4 x 1 ¾ Pounds (800g) of Dry Method
Powder: Grey, Red, Black, and Yellow
- Field Indicator (Magnetometer).
- Certificate of Compliance

Note: The W-WD Kit can be supplied with any model of W-Series Yoke, with our custom fitted Carrying Case.

The W-WD Kit is Ideal for a shop just starting and Magnetic Particle Inspection Program, or a Field Inspector who wants a light and compact MPI Kit with both Dry and Wet Method Particles, Weighing 22 Pounds (10kg).

Phone: (780) 459-6720 Fax: (780) 459-7837 Web: www.westerninstruments.com E-Mail: info@westerninstruments.com