

Western Instruments

Established 1965

26509 Township Road 543
Sturgeon County, Alberta
T8T 1M1 Canada

Phone: (780) 459-6720
Fax: (780) 459-7837
E-Mail: info@westerninstruments.com

Web: www.westerninstruments.com

W-WF Kit (Wet Fluorescent Method)

Spectroline
FL-1700P
12 Volt UV
Lamp Kit



W-WF Kit
Illustrated with a
WC-6 Yoke.

Western's MPI Kits are offered in a great variety of configurations. Our Wet Fluorescent Kit is supplied with 2 of our standard Cases (#3 & #5). Our part number for a WC-6 Wet Fluorescent Kit (as illustrated above) is WC-6-WF. However, any model of Yoke can be supplied and upgraded with a W-WF, with ample room for;

W-WF Kit (Wet Fluorescent Method) includes the following;

(Illustrated with a WC-6)

- #6 Carrying Case
- Aerosol Cans of; (375ml /16 oz.)
 - 4 – Cleaner Remover
 - 4 – Fluorescent Particle Bath
- Economy Pie Gauge
- Field Indicator (Magnetometer).
- Spectroline FL-1700P (12 Volt) Black Light Kit
- #3 Carrying Case
- Western Instruments 7 Amp Hour Battery Pack
- Western Instruments Dual Voltage Charger
- Protective UV Spectacles
- Operator Instructions

Options for BIB-150P or SB-100P Black Lights in #5 Carrying Case.

Note: The W-SWF Kit can be supplied with any model of W-Series Yoke, and is supplied with Sherwin Incorporated® Aerosols, like all of our Wet Method Kits.

The W-DM Kit is Ideal for a shop just starting a Wet Fluorescent Magnetic Particle Inspection Program, or a Field Inspector who wants a Convenient Wet Fluorescent MPI Kit.

Phone: (780) 459-6720 Fax: (780) 459-7837 Web: www.westerninstruments.com E-Mail: info@westerninstruments.com