

Western Instruments

Established 1965

26509 Township Road 543
Sturgeon County, Alberta
T8T 1M1 Canada

Phone: (780) 459-6720

Fax: (780) 459-7837

E-Mail: info@westerninstruments.com

Web: www.westerninstruments.com

W-WM Kit (Wet Method)



W-WM Kit Illustrated
with a WE-7 Yoke.

W-WM Kit (Wet Method) includes the following

Plastic Carrying Case (18.5" x 13" x 10")

Aerosol Cans of;

2 – White Contrast Paint

2 – Black Oxide Bath

4 – Cleaner / Remover

Field Indicator (Magnetometer).

Pie Gauge

Operator Instructions

Note: W-WM Kit can be supplied with any model of W-Series Yoke

The W-WM Kit is Ideal for a shop just starting a Wet Method Magnetic Particle Inspection Program, or a Field Inspector who needs to spend a couple of hours doing a *Black on White* MPI Inspection.

Phone: (780) 459-6720 Fax: (780) 459-7837 Web: www.westerninstruments.com E-Mail: info@westerninstruments.com