

# Western Instruments

Established 1965

26509 Township Road 543  
Sturgeon County, Alberta  
T8T 1M1 Canada

Phone: (780) 459-6720  
Fax: (780) 459-7837  
E-Mail: [info@westerninstruments.com](mailto:info@westerninstruments.com)

Web: [www.westerninstruments.com](http://www.westerninstruments.com)

## W-WF Kit (Wet Fluorescent Method)



W-WF Kit  
Illustrated with a  
WC-6 Yoke.

Spectroline  
FL-1700P not as  
illustrated.

### W-WF Kit (Wet Fluorescent Method) includes the following

Plastic Carrying Case (18.5" x 13" x 10")

Aerosol Cans of;

4 – Fluorescent Bath

4 – Cleaner / Remover

Powder Bulb.

Field Indicator (Magnetometer).

Pie Gauge

Operator Instructions

Spectroline FL-1700P (12 Volt) Black Light Kit

Plastic Carrying Case

Western Instruments' Battery and Battery Charger.

Options for BIB-150P or SB-100P Black Lights.

Note: W-WF Kit can be supplied with any model of W-Series Yoke

The W-DM Kit is Ideal for a shop just starting a Wet Fluorescent Magnetic Particle Inspection Program, or a Field Inspector who wants a Convenient Wet Fluorescent MPI Kit.

Phone: (780) 459-6720 Fax: (780) 459-7837 Web: [www.westerninstruments.com](http://www.westerninstruments.com) E-Mail: [info@westerninstruments.com](mailto:info@westerninstruments.com)