

Western Instruments

Established 1965

26509 Township Road 543
Sturgeon County, Alberta
T8T 1M1 Canada

Phone: (780) 459-6720

Fax: (780) 459-7837

E-Mail: info@westerninstruments.com

Web: www.westerninstruments.com

W-DMB Kit (Basic Dry Method)



W-DMB Kit
Illustrated with a
WC-6 Yoke

W-DMB Kit (Basic Dry Method) includes the following

Plastic Carrying Case (14.7" x 10.6" x 3.3")

Powder Bulb.

2 x $\frac{3}{4}$ lbs. of Powder (2 of; Grey or Red or Black, or Yellow Powder)

Field Indicator (Magnetometer).

Operator Instructions

Note: W-WMB Kit can be supplied with any model of W-Series Yoke

The W-DMB Kit is Ideal for a shop just starting and Magnetic Particle Inspection Program, or a Field Inspector who wants a light and compact MPI Kit.

Phone: (780) 459-6720 Fax: (780) 459-7837 Web: www.westerninstruments.com E-Mail: info@westerninstruments.com