



# Western Instruments

Established 1965

26509 Township Road 543  
Sturgeon County, Alberta  
T8t 1M1 Canada

Phone: (780) 459-6720  
Fax: (780) 459-7837  
E-mail: [info@westerninstruments.com](mailto:info@westerninstruments.com)

Web: [www.westerninstruments.com](http://www.westerninstruments.com)

## Portable MPI Kit Descriptions

July 2015

### Carrying Cases

**W-BC Yoke Carrying Case** - Small padded Case for Yokes

14" L x 11" W x 3-1/4 H.

**W-KC Yoke Kit Carrying Case** – Used for Dry Method and basic Wet Method Kits

16" L x 12" W x 4" H.

**W-TC Yoke Tool Box** – Used on Wet/Dry and Wet Method Kits

18" x 13" x 10"

### W-DMB Kit (Basic Dry Method)

Plastic Carrying Case (14.7" x 10.6" x 3.3")

Powder Bulb.

2 x 3/4" lbs. of Powder (Grey, Red, Black, or Yellow Powder

Field Indicator (Pocket Magnetometer).

Operator Instructions

### W-DM Kit (Deluxe Dry Method)

Plastic Carrying Case (14.7" x 10.6" x 5.3")

Powder Bulb.

4 x 1.75 lbs. Grey, Red, Black and Yellow Powder

Field Indicator (Pocket Magnetometer).

Operator Instructions

### W-WMB Kit (Basic Wet Method)

Plastic Carrying Case (18.5" x 13" x 10")

Aerosol Cans of; 1 - Black Prepared Bath

1 - White Contrast Paint

1 - Cleaner/Remover

Field Indicator (Pocket Magnetometer).

Operator Instructions

### W-WD Kit (Wet/Dry Method)

Plastic Carrying Case (18.5" x 13" x 10")

Aerosol Cans of; 1 - Black Prepared Bath

1 - White Contrast Paint

2 - Cleaner/Remover

Powder Bulb.

4 x 1.75 lbs. Grey, Red, Black and Yellow Powder

Field Indicator (Pocket Magnetometer).

Operator Instructions

**W-WM Kit (Wet Method)**

Plastic Carrying Case (18.5" x 13" x 10")  
Aerosol Cans of; 2 - White Contrast Paint.  
2 - Black Particle (water base).  
4 - Cleaner/Remover.  
Field Indicator (Pocket Magnetometer)  
Operator Instructions

**W-WF Kit (Wet Fluorescent)**

Plastic Carrying Case (18.5" x 13" x 10")  
Aerosol Cans of; 4 – Fluorescent Particle Bath  
4 - Cleaner/Remover.  
Spectronics FL-1700P (12 Volt) Black Light (In Separate Carrying Case)  
Plastic Carrying Case (14.7" x 10.6" x 5.3")  
7 Amp Hour Battery Pack  
Battery Charger  
UV Spectacles  
Field Indicator (Pocket Magnetometer)  
Operator Instructions  
Also available with Spectronics BIB-150P, SB-100P, or Trrtan 365

**W-SWF Kit (Self-Contained Wet Fluorescent)**

Plastic Carrying Case (18.5" x 13" x 10")  
Aerosol Cans of; 4 – Fluorescent Particle Bath  
4 - Cleaner/Remover  
Field Indicator (Pocket Magnetometer)  
Operator Instructions  
Western SPR Long Wave UV LED Flash Light (Torch)  
Spare Battery  
Battery Charger with AC and 12VDC Adaptors  
UV Spectacles  
Field Indicator  
Operator Instructions

**Kit Refills**

Western offers Refills for our Portable MPI Kits. Simply quote the following numbers when requesting a Refill;

W-DBM	K-121
W-DM	K-122
W-WMB	K-123
W-WD	K-124
W-WM	K-125
W-WF	K-126
W-SWF	K-126

**Kit Delivery**

When a Kit or Carrying case is purchased with a W-Series Yoke, the Kit is equipped with a pocket or storage space for a Yoke to be placed in.