



Western Instruments

Established 1965



Sherwin's *DR-60* is a solvent based Cleaner / Remove primarily intended for use in Dye Penetrant Inspection. However, for use in Western Instruments W-Series Magnetic Particle Inspection Kits, *DR-60* is used to remove excess White Contrast Paint, such as *CP-2* from a workpiece.

If a workpiece is oily before a Wet or Wet Fluorescent Method Magnetic Particle Inspection, *DR-60* is recommended to pre-clean the inspection area of the workpiece. However, if the workpiece is a steel fabrication, that will be sandblasted or will not be re-coated, *CP-2* can be left on the workpiece to inform others that an inspection is complete.

Applicable MPI Specifications

ASTM-E-1444
ASTM-E-709AMS-3042
ASME Section V
ISO 9934
NAVSEA 271-97
MIL-STD-1949 E

Competitor Equivalent

Ardrox PR-1
Magnaflux SKC-S

Phone: (780) 459-6720 Fax: (780) 450-6720 Web: www.westerninstruments.com E-Mail: info@westerninstruments.com